Voyager One

59010601 Voyager One Ballast ECC HP

Voyager One

Spare control gear for Voyager One range:

For replacement, please refer to the installation instructions for the luminaire.

ZS_RES_F_ECD_1.jpg

All values marked with an * are rated values. Unless stated otherwise, the values apply to an ambient temperature of 25°C.

Thorn Lighting is constantly developing and improving its products. The right is reserved to change specifications without prior notification or public announcement.
© Thorn Lighting